

## Section 4

AHB PARTS DESCRIPTION : SYSTEM 8 MARK 3

SPRING 1986

To order spare parts for service replacement specify the items as follows:

FUNCTION	ITEM	AHB STOCK NUMBER
Fader	100mm 10k Alps	AI0091
Fader knob	Black Alps	AJ0048
Fader screw	M3 CSK 5mm	AB0070
Meter	SQ10	AD0011
Meter bulb	8v 50mA SQ10	AD0013
Knob	6mm grey	AJ0050
Knob cap	Red	AJ0045
	Grey	AJ0092
	Blue	AJ0052
Pushbutton cap	4748 black	AJ0028
Base screw	6AB x $\frac{3}{8}$ PAN	AB0062
Base captive nut	SNU2945	AB0111
Input Pot Gain	10KC metric bkt	AI0049
H.F.	100KA metric	AI0047
L.F.	100KA metric	AI0047
Mid	100KA metric	AI0047
Mid freq	100KC x 2 metric	AI0048
Aux 1, 2, 3	47KB metric	AI0050
Pan	10KA metric bkt	AI0046
Output Pot Level	10KB metric	AI0043
Aux 1, 2/3	47KB metric	AI0050
Pan	10KA metric bkt	AI0046
Master Pot Aux 1	47KB metric bkt	AI0045
Aux 2, 3	47KB metric	AI0050
Cue	10KB x 2 metric	AI0044
Level	47KB metric	AI0050
Aux 1, 2	47KB metric	AI0050
Pan	10KA metric bkt	AI0046
Talkback level	47KB metric bkt	AI0045
Headphone level	10KB x 2 metric	AI0044
Monitor level	10KB x 2 metric	AI0044
Switch	Single Alps 2PCO	AL0162
Switch Talkback	Alps momentary 4PCO	AL0340
Switch Fader Reverse	Alps latching 4PCO	AL0333
IC op-amp	TLO72CP	AE0046
IC op-amp	NE5534N	AE00
Input transistor	BC214C	AE0031
Red LED	T1 Red	AE0086
Relay PFL	NF2-12	AM0208
Jack socket Insert	S2BBB	AL0080

## AHB PARTS DESCRIPTION : MPS8P POWER SUPPLY

SPRING 1986

To order spare parts for service replacement specify the items as follows:

FUNCTION	ITEM	AHB STOCK NUMBER
Fuse	500mA $\overline{A}$ T 20mm	AL0304
Fuse (USA and Japan)	1 AT 1 $\frac{1}{4}$ "	AL0315
Transformer	P1025	AM0021
Bridge rectifier	2A 200V	AE0090
Bridge rectifier	1A 200V	AE0089
IC regulator +	7815	AE0047
IC regulator -	7915	AE0048
Transistor	TIP 31B	AE0073
Zener diode	47V BZX61	AE0008
IC insulating kit	mica washer + bush	AA0560